

# Pin Configuration

Applicable for ER and CR type cylindrical model

|   |   |   |
|---|---|---|
| <p style="text-align: center;">- / T</p> <p style="text-align: center;">- / 2PT</p>   | <p style="text-align: center;">- / 3PT</p> <p style="text-align: center;">- / 3TP</p> | <p style="text-align: center;">- / P</p>                              |
| <p style="text-align: center;">- / 3PT</p> <p style="text-align: center;">- / 3TP</p> | <p style="text-align: center;">Connector Type 1</p>                                   | <p style="text-align: center;">Case Type 1<br/>(water proof case)</p> |
| <p style="text-align: center;">- / 3PF</p> <p style="text-align: center;">- / 3FP</p> | <p style="text-align: center;">Case Type 1<br/>(water proof case)</p>                 | <p style="text-align: center;">Case Type 2</p>                        |
| <p style="text-align: center;">- / 4PT</p> <p style="text-align: center;">- / 4PF</p> | <p style="text-align: center;">Case Type 2</p>  | <p style="text-align: center;">Case Type 2</p>                        |

\*\*Note: The data in this document are for descriptive purposes only and subject to change without prior notice.